# **PCM 37**

**Pure Phase Change Material** Phase Change: 37°C, 98.6°F

#### DESCRIPTION

Pure (or raw) Phase Change Materials (PCMs) are substances which can store and release large amounts of energy by undergoing a phase change between its liquid and solid states.

As the PCM cycles between the liquid and solid states it holds the temperature around its particular melt point. PCMs are unique in that they provide a completely passive thermal regulation system. Under the proper conditions, PCMs can cycle thousands of times. Microtek offers pure PCMs with melt points in the range of -30°C to 57°C. Custom temperatures are available.

# **APPLICATIONS**

Pure PCMs are used to regulate temperatures by providing both cooling and heating effects, and for heat storage, in a variety of applications. Pure PCMs are widely used in application areas such as:

- Thermal Energy Storage (TES) heat storage and release in conjunction with solar energy and HVAC systems.
- Electronics for cooling electrical components in tablets, phones, laptops, data centers, and remote-access equipment such as telecommunication stations.



### PROPERTIES

The PCM 37 typically exhibits these general properties:

Typical Properties	
Appearance	Above melt point: Liquid, colorless Below freeze point: Solid, opaque
Form	Bulk
Туре	Paraffin
PCM Content	100%
Melting Point	37°C (98.6°F)
Heat of Fusion	210-220 J/g
Thermal Cycling	Multiple

#### PACKAGING

This product is generally shipped in I gallon pails (6 lbs) or 55 gallon drums (330 lbs).

# **HEALTH AND SAFETY**

Please refer to the Safety Data Sheet (SDS) for necessary safety and handling precautions for this product.

Visit **www.microteklabs.com** or call **937.236.2213** for more information on your thermal management needs.

IMPORTANT NOTE: This data has been compiled from testing that Microtek Labs believes reliable and is supplied for informational purposes only. Microtek Labs encourages purchasers to validate this data and the product's fitness for use in the purchaser's process by performing their own tests.

MT19-026 PCM 37 PDS © 2019 Microtek Laboratories, Inc. All Rights Reserved. All other trademarks are the properties of their respective owners.

MPDS3300-0009

Revision 2

Effective Date: 03/14/2020

